



DJI Osmo Action 3 Multifunctional Battery Case

DJI Osmo Action 3 Multifunctional Battery Case

Osmo Action 3 multifunctional battery case

The case stores 3 rechargeable batteries and 2 microSD cards. It quickly charges the 3 batteries and can be used together as a powerbank to charge other devices such as a smartphone.

Ref: 6941565945020

Specification:

Manufacturer

DJI

Name

Osmo Action 3 multifunctional battery case

Dimensions

116.2 × 59.2 × 22.9 mm

Weight

110 g

Price:

€ 59.00

Drones, Accessories, DJI, Osmo