



Osmo Action Biking Accessory Kit

Ref: 6941565945471

Osmo Action Biking Accessory Kit

Osmo Action bike accessory kit

Capture your next bike trip from an unusual perspective. The kit includes a handlebar mount and a chest mount, so you can stably mount your DJI Osmo Action, DJI Action 2 or DJI Osmo Action 3 camera in the desired location and effortlessly produce a breathtaking video. Focus on the joy of the ride and create plenty of original, dynamic shots! The accessories are very easy to install and stand out for their high durability.

In the box

Chest mount

Handlebar mount

Locking screw x2

Specification

Brand

DJI

Handlebar mount dimensions

182.31x72.96x25.60mm

Handlebar mount weight

149g

Chest mount dimensions

340x230x74mm

Chest mount weight

216g

Screw dimensions

55.6x23x13.3mm

Screw weight

11.2g

Compatibility

DJI Osmo Action 3, DJI Action 2, DJI Osmo Action

Price:

€ 70.00

Photo, Video, Cameras, DJI Osmo Action