



Food grinder Deerma JS100

Food grinder Deerma JS100

Ref: 6955578036804

The food chopper you need

The Deerma JS100 is a compact electric food chopper that's perfect not only in any kitchen, but also when traveling, for example. Thanks to its capacious battery, it can be used up to 30 times on a single charge. A powerful motor ensures high efficiency of the device, and a convenient button makes it easy to operate. The set also includes a small scraper, with which you can thoroughly clean the walls of the container from food residues.

Long battery life

The chopper is equipped with a 1500 mAh battery, which is responsible for its impressively long runtime. You can conveniently charge the device using the USB-C cable - it only takes about 2 hours! You don't have to worry about having to charge it too often. Deerma JS100 will surprise you with its performance.

It will chop food very qucikly

The JS100 motor is very powerful. It can chop food at up to 60 times per second. So no matter what you want to cook, this functional appliance will do the job perfectly. It will chop vegetables, fruit or meat in no time. With its help you can also quickly prepare garlic and other seasonings.

Mobilemax - Gadgets and Accessories Rua Vasco da Gama n61, 8005-411, Estoi - Faro, Portugal (Continente) Phone: +351962484153 (Call to national mobile network) Email: info@mobilemax.pt



Easy to use

Operating the appliance is incredibly easy. Mount the blades in it, place the food in the container and close the lid. Then just press the big button on the lid. When the chopper is done, simply empty it! The included scraper makes it easier for you. That's all it takes to enjoy perfectly cooked food every day.

Safe to use

The 150 ml AS plastic container is transparent, so you can see what's happening with your food all the time. The blades are made of durable stainless steel. Both parts of the chopper are completely safe and pose no risk to food in contact with it. You can also wash them under running water and sanitize them with heat to keep it clean and safe. The chopper is a successful combination of functionality and compactness. Its small dimensions of 90x90x112 mm mean it doesn't take up too much space. This makes it ideal also for small kitchens. This small size combined with its light weight means you can take it with you wherever you go - on vacation, on a picnic or in a camper van.

Brand Deerma Model JS100 Power consumption 40W Power supply DC 3.7V / 11A Dimensions 90 x 90 x 112 mm Capacity 150ml Charging time Approx. 2h Working time Up to 30s Battery 1500mAH

Price:

€ 16.49

Lifestyle&Outdoor, Other, Home Accessories