



Magnetic two claw adapter for DJI Action 3 Camera

Magnetic two claw adapter for DJI Action 3 Camera

Ref: 6974944460982

Telesin mount for DJI Action 3 camera

Gain a new perspective in your footage with the Telesin adapter. It was created for DJI Action 3 cameras and guarantees instant mounting in the mount with a powerful magnetic base, ensuring stability and security for your device. A metal clip provides additional security to protect your device from unwanted knockdown, ensuring reliability in all conditions.

Universal application

The Telesin mount is fully compatible with DJI Action 3 cameras, making it a convenient solution for users of this model. Mounting with a double cold shoe allows you to easily attach the camera to a selfie-stick, tripod, bike frame, or neck mount, allowing you to record in a variety of scenarios - from extreme sports to everyday shots.

Lightweight, portable and durable

Robust construction made of high-quality materials makes the camera mount reliable in all conditions. The adapter's light weight and compact size means it can accompany you anywhere, allowing you to mount your camera wherever you need it in no time. This way you won't miss the perfect opportunity to create unique shots.

Included

Adapter
Screw
□Manufacturer
□Telesin
□Model
□OA-TPM-T04
□Material
□Nylon + fiber; aluminum alloy, silicone
□Dimensions
□40.2 x 21.3 x 33.8 mm
□Weight
□22.8 g
□Compatibility
□DJI Action 3 cameras

Preço:

€ 11.50

Fotografia, Other, Video, Acessórios