



DJI Action 2 Waterproof Case

DJI Action 2 Waterproof Case

Ref: 6941565919861

Waterproof case for DJI Action 2

Fearlessly record spectacular footage underwater. The Waterproof Case for DJI Action 2 will accommodate your camera with the Front Touchscreen Module or Power Module and allow you to safely use them at depths of up to 60m. The high-strength glass ensures a clear, readable display in almost any condition. The case also has a special button that allows you to conveniently press the DJI Action 2 power / record button.

Note: before use, make sure the case is dry and the lock screw is properly installed. Also check that the waterproof sealing ring is clean, intact and properly installed. Before using the case, we recommend submerging it in water for about 5 minutes to make sure it works properly.

Specification

Brand

DJI

Name

DJI Action 2 Waterproof Case

Weight

88g

Dimensions

108x64x33mm

Compatibility

DJI Action 2

Preço:

€ 49.00

Drones, Photo and cameras, Acessórios, DJI, For sports cameras, Osmo